

Application Note

Regent to Trusted Migration

This document describes the steps needed to replace a Regent processor chassis with a Trusted processor chassis. This replaces the Regent processor and communications modules and providing a future path to expansion of the Trusted system side. It assumes a knowledge of Trusted application design.

Issue Record

Issue Number	Date	Revised by	Technical Check	Authorised by	Modification
1	June 08	Nick Owens	Andy Holgate	Pete Stock	Initial Issue
2	June 08	Nick Owens	Andy Holgate	Pete Stock	Corrections

1. Hardware

The migration principles are identical for Regent (panel mount) and Regent +Plus (rack mount) because the internal circuitry is the same, as is the software. In this document, the term 'Regent' is used for both variants.

The Regent processor chassis with processor and communications modules is replaced by a Trusted processor chassis with communications modules. The T8160 TMR Interface module (otherwise known as the Regent interface module, or RIM) bridges the triplicated Regent Safetybus into the Trusted Inter-Module Bus (IMB). The T8160 has a choice of two companion slot cables TC-320-01 and TC-321-01. TC-320-01 ends in three connectors that fit the Regent chassis sockets. TC-321-01 ends in three connectors that fit the existing Safetybus cables. This allows a choice of running new cables to the first expander chassis or using the extra length of the existing cables.

The Trusted processor chassis is 6U high but also needs a 2U T8270 fan tray mounted above it. It should not be located directly above bulk power supplies or other significant sources of heat, as air is drawn from underneath the chassis.

A Trusted system requires one T8110B processor module (which contains three identical processors). The chassis also has a companion processor slot to allow faulty processors to be replaced. For a Trusted-Regent hybrid, one T8160 TMR interface module is required, and this is also fitted in a companion slot, taking two of the eight single width slots. To replace the three Regent communications modules, two Trusted T8151B communication interface modules are adequate. These each contain four high speed serial ports and also two Ethernet ports. They support Modbus (master and slave) and native Trusted peer networks, but will not support Regent Peer to Peer networks or the Regent Guarded Peer link. Modbus Master requires a T8122 or T8123 Processor interface adapter.

AN-T80017 Regent to Trusted Migration

1.1. Parts List

T8100	1off	Processor Chassis
T8270	1off	Fan Tray
T8110B	1off	Processor module (recommended spares holding of 1)
T8160	1off	TMR Interface (recommended spares holding of 1)
T8151B	2off	Communications Interface
Optional T812x	1off	Processor Interface Adaptor (T8120,1,2,3 as appropriate for IRIG and Modbus Master licenses; see PD-T812X)
T8153	2off	Communications Interface Adapter for serial and Ethernet connection
TC-320-01	1off	Interface cable to plug into first Regent expander chassis OR:
TC-321-01	1off	Interface cable to chain to existing cables

Recommended power supply for Trusted:

T8240	1off	Power shelf for three Power Packs
T8231	2off	750W 24Vdc Power Pack
MCBs		On AC (6A) and DC sides (20A)

Recommended replacement for Regent system power supplies is required (see PD-T8200 for options):

T8200	1off	Power supply chassis (or T8201) (room for 6 modules)
T8220	3off	Power supply module 15V (3off per 4 Regent chassis)
T8294	1off	Supply adaptor board (1off per 4 Regent chassis)

3. Installation

Both the Regent and Trusted are 3-2-0 degradation systems. When fully healthy, all three slices are working (3). On one fault, the remaining two slices can continue operating as long as they agree (2). On a fault in one of the two remaining slices, the system shuts down (0).

This provides higher integrity than 3-2-1-0 since at least two system slices must be operational for the system to be operational, allowing instant and robust diagnostics through voted comparison. However, since each system requires two of the three slices to operate, an online changeover is not possible and the changeover must be made with the system in shutdown.

The new Trusted chassis may be fitted in place of an existing rack-mounted Regent+Plus processor chassis if time is available for physical installation, or it may be fitted in spare space nearby whilst the existing system is operating. The standard TC-321-01 cable is 4 metres long, but the existing Regent Safetybus cables to the Regent processor chassis may also have slack inside trunking, or it may be possible to route them differently to gain length.

Power the Regent I/O chassis first and allow them to start. Then power the Trusted processor chassis with the Safetybus connected. If the Trusted application and system.INI are correct, the application will start and the application can be commissioned.

4. Application

There is no automated tool for application conversion from Regent to Trusted, and the applications are very different. However, it is possible to copy the functionality with the resulting programs looking similar to the original programs. Use the following steps to ease the process.

In this section, 'Winterpret' is used as the name of the Regent application tool. Its predecessor was PDS, which is still in use on the older Regent systems. The presentation is different but the core functionality is similar.

A copy of Winterpret (or PDS) will be necessary to read the Regent configuration. This does not need to be the same issue as used before, but must be loaded with the same extra packages.

4.1. System Configuration

The System.INI file for a Trusted-Regent hybrid is very simple. Insert a T8160 TMR Interface into the chassis, and insert another T8160 in its companion slot to the right. This allows the system to black-start with the T8160 in either slot. By convention, slots 1 and 2 are used.

Insert T8151 communications interfaces into the chassis. By convention, slots 7 and 8 are used.

This leaves four slots spare for Trusted I/O modules and interfaces to future Trusted expansion I/O chassis, which will have a much smaller panel space than the corresponding Regent I/O equivalent.

Configure the communications interface parameters. Replicate the serial port settings from Regent (baud rate, bits and parity). For Modbus slaves, enable slaves on the ports as appropriate. For Modbus Master, create a Modbus Master and define its slaves and messages as in the Regent application. For further information, refer to product description PD-T8151B.

4.2. Toolset I/O Connection Table

The first step is to build the I/O connection table. Add definitions for modules in the Trusted chassis first.

ttmrp	Trusted processor	Only one definition required
ttmri_ii	TMR Interface	One ttmri_ii definition covers both module positions

There is no need to add definitions for the communications interfaces. If the TMR Interface was not placed in the left-hand slot of the eight narrow slots in the Trusted processor chassis, correct the Slot number on each of the two boards of the ttmri_ii definition.

Now add the definitions for each Regent I/O module. It is recommended to place these definitions in the order that they appear in the chassis and slots, but the only real constraint is that 7491 multiplexer modules must be defined before their multiplexer I/O. Product description PD-T8160 describes each definition. These definitions each provide connection boards for variables used in the application.

Each definition for a Regent module must be set up with the following parameters:

TICS_CHASSIS and _SLOT	The chassis number (1) and the slot number (usually 1) of the T8160 TMR Interface. (It helps here if the T8160 is in the default position, chassis 1 slot 1).
REGENT_CHASSIS and _SLOT	The position of the Regent module; the first I/O chassis is chassis 1.

There will be further parameters for the second and third module position in definitions applying to multiple module sets.

Copy these parameters to the entry points on each board.

AN-T80017 Regent to Trusted Migration

Channel LEDs may be prevented from showing faults using the MONITOR_MASK as in Winterpret. The digital input monitoring thresholds are also entered on board parameters, as are any other parameters required in the Winterpret application.

4.3. Declaration of variables

In Regent, the Modbus address map is automatically assigned to variables according to their position in the list. This often means that spare variables must be declared to fill in gaps between address blocks. In Trusted, each variable is assigned an address separately, and so spare variables are not necessary.

PD-T8160 describes the connection points available on each I/O module definition. These may be different to Regent. For example, digital inputs in Regent can be read individually using digital shared control relays and also as a 16-bit word using shared registers. The definitions in Trusted will arrange the data differently, including differences for definitions connecting to single, dual and triple module sets and for open and packed data.

4.4. Replacement of Scale function blocks

Winterpret applications can have SCALE function blocks which convert input signals (as 0-4095) into engineering units, including square root extraction if necessary. These may be replaced using conversion tables in the Trusted analogue dictionary. The values and data available to the Regent application will be in the same format and scaling in the Trusted application.

4.5. Replacement of Ladder function blocks

Winterpret has a fixed grid for its ladder logic with ten columns, the last of which must be a coil output. The Trusted Toolset can handle ladder programs in two different editors. The Function Block Diagram editor can program ladder logic using a switch on the toolbar. In this editor, ladder elements can be placed anywhere on the screen and wired together; the left-hand inputs must be wired from a power rail element. Essentially this is function block diagram programming using elements that look and act like ladder logic elements.

There is also a 'Quick LD' editor, which allows creation and insertion of ladder elements and rungs, automatically arranging branches in a fixed format. This may prove quicker to some programmers, but it does not allow the flexibility of FBD ladder arrangement.

Trusted FBD ladder is executed according to the hierarchy of inputs; a block will not execute until its inputs are ready. The program execution will therefore work its way from farthest inputs through to final outputs.

Regent ladder executes down each column in turn for each rung. It is possible to create logic which relies on this execution order for its operation. Therefore be aware that Trusted FBD ladder may interpret the execution order differently to Winterpret ladder. The FBD editor has an option 'Show Execution Order' which numbers function blocks and outputs in the order they are executed. Moving logic on the screen may change this order but it is best practice to separate rungs to force the execution order because in either language, the rungs are executed in order from top to bottom.

Regent function blocks are described in the Regent Software reference manual. The most common complication is timers. Winterpret has one timer block with inputs for 'time' (increment the accumulator) and 'enable' (allow incrementing when true or reset the count when false). Usually these inputs are shorted together, so it acts as a delay-on timer like Trusted's TON, but they may be separate. If separate, the timer will be part of a latch to define other actions like TP. It has two outputs which are the permanent inverse of each other; the upper output goes true on timeout.

AN-T80017 Regent to Trusted Migration

4.6. FLOAT function blocks

These are very similar to Trusted structured text programs, and were designed to handle floating point arithmetic. Winterpret ladder programs can only handle integer arithmetic. These may be replicated as structured text in Trusted.

4.7. MODBUS MASTER function blocks

These are replaced by the Modbus Master editor in the Trusted system configurator, for the appropriate communications interface. The basic structure of declared slaves and assigned messages is the same.

4.8. SOE function blocks

These created event lists from a list of shared control relays assigned for SOE collection. These function blocks are replaced with SOE boards in the I/O connection table. Similarly, Process Historian function blocks are replaced with PH boards in the I/O connection table.

4.9. PID function blocks

PID blocks are replaced with ipid function blocks inside FBD programs, from the T8019 Process Control package. Refer to PD-T8019 for details on their operation.

4.10. Program Load

Regent allowed the I/O table and shared variables to be loaded as a foundation, with programs of function blocks loaded and controlled individually on top. Trusted only has one application download and relies on online updates for modifications.

The Trusted application will only run when all I/O module definitions match the system as discovered. On failure, the message 'cannot open board' will be shown for each failed board, giving the table row on which the definition is placed.

4.11. Diagnostics

A Trusted-Regent hybrid is essentially a Trusted system with unusual I/O modules. The fault history is replaced by entries in the processor event log (ls d). The fault table is replaced by diagnostic command 'rio'. This provides tables of the configured and actual modules. It also provides tables of transient and permanent faults in text form, replacing the yellow and red icons in the Winterpret fault table. To see the command syntax, type 'rio'.

The clock in Regent may be set in a pop-up window; the nearest equivalent in Trusted are the diagnostic commands 'fps q' to display the clock and 'fps d ...' to set the clock.

4.12. System variables

Regent has fixed tables of system diagnostic data which do not exist in Trusted. Equivalent Trusted information can usually be found in the diagnostic boards on each module definition in the I/O connection table.

AN-T80017 Regent to Trusted Migration

5. Application Examples




Figure 3 Regent I/O Module Configuration

Regent I/O configuration allows names to be applied to each I/O point and fault point which do not appear in the shared variables (the equivalent of the Trusted dictionary). It also allows the naming of 16-bit registers to carry all I/O points or faults in one tag, as shown above. The I/O operation is configured in the table (thresholds, redundant modules etc.).

AN-T80017 Regent to Trusted Migration

In Trusted, all variables must be named in the dictionary and then connected to the appropriate data point on the board definition. The OEM parameters are used to specify the I/O operational parameters. The board definitions also handle some of the voting required, e.g. there is only one DO board below for both modules but two fault boards.




Figure 4 Trusted I/O Module Configuration

AN-T80017 Regent to Trusted Migration

The Regent multiplexer module is a special case. This has multiple sub-windows for each multiplexer slave input or output board. Each multiplexed point can be given a name.




Figure 5 Regent Multiplexer Configuration

AN-T80017 Regent to Trusted Migration

The Trusted implementation for multiplexed I/O is to use many separate I/O definitions. The Regent 7491 module should be declared before the I/O boards. Again, OEM parameters are used to define the board addresses.




Figure 6 Trusted Multiplexer Configuration

AN-T80017 Regent to Trusted Migration

Regent variables can be declared in the Shared Variables lists as Control Relays (Booleans), Registers (integers) and Floating Point Registers (reals). Variables can also be declared in the I/O connection table as the name of I/O data points, and even implicitly as local variables inside function blocks.

Trusted variables must all be declared in the dictionary lists and used in the I/O connection table and programs.

Regent shared variables are addressed by their position in the list, e.g. the variables here are at Modbus address 0600 onwards. Trusted variables may be allocated individual addresses or none at all. Regent often requires spare variables to space out the addresses; these are not needed in Trusted.




Figure 7 Regent Shared Control Relays and the Trusted equivalent

AN-T80017 Regent to Trusted Migration

Winterpret shared registers and shared floating point registers are in separate lists. Trusted integers and reals are all in the same list.




Figure 8 Analogue variables

AN-T80017 Regent to Trusted Migration

Winterpret allows multiple programs, each containing function blocks in different languages. Each program may be loaded and controlled separately. Trusted applications have only one 'program' containing multiple 'function blocks' by comparison, though the descriptive terms are different.




Figure 9 Regent and Trusted programming hierarchy

Regent ladder logic function blocks are on a fixed grid with 10 columns wide. Trusted FBD/LD programs allow free design with user function blocks. These two programs are not identical in their operation.




Figure 10 Ladder Logic and FBD Programs

AN-T80017 Regent to Trusted Migration

Regent is capable of floating point arithmetic in separate Math function blocks, using a structured text language similar to Trusted ST. In this case, FBD has been used as its replacement.

The image displays two software windows. The top window, titled 'WINTERPRET', shows a project named 'Project 'PA2'' with a 'Math Function Block 'FP_MATH', Vers. 0010'. The code in this window is as follows:

```
CCPCON 0004 CONTROLS ANNUNCIATORS & RETAYS FOR CCR
OCI
GRV
MOI FT
OP1 VC LINE_NUM=0
SO1 SC ERROR_CODE=0
TES A
U7: FC : MOLE AIR FLOW RATE
      FT73A01_M1=AIS_SP03/28.84
U7: LC :
U7: FC : MOLE O2 FLOW RATE
      FT73A01_M2=(FTS73A01/1000)/32.0
U8: FC :
U8: LC :
U8: FC : AIR/O2 FLOW RATIO
      FR73A01_A=((FT73A01_M2+(0.21*FT73A01_M1))/(FT73A01_M1+FT73A01_M2))*100
      : CONVERT FLOATING POINT TO INTEGER
      FR73A01_B=FR73A01_A*10
U9: FC :
U9: LC :
U9: FC : MOLE AIR FLOW RATE
      FT73A06_M1=FTS73A07/28.84
      : MOLE O2 FLOW RATE
      FT73A06_M2=(FTS73A06/1000)/32.0
      : AIR/O2 FLOW RATIO
      FR73A06_A=((FT73A06_M2+(0.21*FT73A06_M1))/(FT73A06_M1+FT73A06_M2))*100
      : CONVERT FLOATING POINT TO INTEGER
      FR73A06_B=FR73A06_A*10
```

The bottom window, titled 'IEC1131 TOOLSET - SRC:PRG22 - FBD/LD Program', shows a ladder logic diagram for 'CALCULATE AIR/O2 FLOW RATIO FOR FT73A01'. The diagram includes the following elements:

- Inputs: FTS73A08 (28.84), FTS73A01 (1000.0), FTS73A01 (32.0), FT73A01_M1 (0.21), FT73A01_M1 (0.0002), FT73A01_M2 (100.0), FR73A01_A (10.0), FR73A01_B (290.0), T13, 0, and 3.
- Operations: Division (N1, N2, G), multiplication (*), addition (+), subtraction (-), comparison (<), and selection (sel).
- Outputs: FT73A01_M1, FT73A01_M2, FR73A01_A, FR73A01_B, FRSHH73A01, and FRAHH73A01.

Figure 11 Floating Point Maths

AN-T80017 Regent to Trusted Migration

Regent has scaling functions as a separate function block language. These may be implemented with conversion tables or with programming in ST, or using FBD as implemented here.




Figure 12 Scaling functions

AN-T80017 Regent to Trusted Migration

Regent has a separate function block language for defining points to be collected by Sequence of Events. In Trusted, the evented points may be configured as outputs and wired to SOE boards (there is no native SOE on Regent I/O modules when in a hybrid system).




Figure 13 Sequence of Events

AN-T80017 Regent to Trusted Migration

Communication settings are very different, by definition of the different architecture. Regent can have six ports which may be for diagnostics (COMM), text output (ASCII), Modbus slave or master or Regent Peer network. Trusted does not need allocation of a diagnostic port, and does not implement text output or Regent peer network. In this case, the ports are essentially unused.




Figure 14 Port Configuration

Trusted™

AN-T80017 Regent to Trusted Migration



ICS Triplex technologies and services are available worldwide.

Hall Road

Maldon Essex

CM9 4LA

UK

Tel: +44 1621 854444

Fax: +44 1621 851531

www.icstriplex.com

For technical support email: support@icstriplex.com

Sales enquiries: sales@icstriplex.com

Technology Driven Customer Led