


HIMatrix

Safety-Related Controller

DIO 24/16 01 Manual



HIMA Paul Hildebrandt GmbH + Co KG
Industrial Automation

All HIMA products mentioned in this manual are protected by the HIMA trade-mark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the CD-ROM and our website <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2010, HIMA Paul Hildebrandt GmbH + Co KG

All rights reserved

Contact

HIMA Address

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Tel: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com

Revision index	Revisions	Type of Change	
		technical	editorial
1.00	Added: Configuration with SILworX	X	X
1.01	Table 11, digital outputs	X	X

Table of Contents

1	Introduction	5
1.1	Structure and Use of this Manual	5
1.2	Target Audience	6
1.3	Formatting Conventions	6
1.3.1	Safety Notes	6
1.3.2	Operating Tips	7
2	Safety	8
2.1	Intended Use	8
2.1.1	Environmental Requirements	8
2.1.2	ESD Protective Measures	8
2.2	Residual Risk	9
2.3	Safety Precautions	9
2.4	Emergency Information	9
3	Product Description	10
3.1	Safety Function	10
3.1.1	Safety-Related Analog Inputs	10
3.1.1.1	Reaction in the Event of a Fault	10
3.1.2	Safety-Related Outputs	11
3.1.2.1	Reaction in the Event of a Fault	11
3.1.3	Line Control	11
3.2	Equipment, Scope of Delivery	11
3.3	Type Label	11
3.4	Assembly	13
3.4.1	Block Diagram	13
3.4.2	Front View	14
3.4.3	Module Indicators	15
3.4.4	I/O LEDs	15
3.5	Product Data	15
4	Start-Up	17
4.1	Installation and Mounting	17
4.1.1	Mounting and Removing the Modules	17
4.1.2	Connecting the Digital Inputs	18
4.1.2.1	Surges on Digital Inputs	19
4.1.3	Connecting the Digital Outputs	19
4.1.4	Mounting the DIO 24/16 01 in Zone 2	20
4.2	Configuration	21
4.2.1	Module Slots	21
4.3	Configuring the Module with SILworX	21
4.3.1	Parameters and Error Codes for the Inputs and Outputs	22
4.3.2	Digital Inputs and Outputs	22
4.3.2.1	Module Tab	22

4.3.2.2	DIO 24/16 01_1: DO Channels Tab	24
4.3.2.3	DIO 24/16 01_1: DI Channels Tab	24
4.4	Configuring a Module Using ELOP II Factory	25
4.4.1	Configuring the Inputs and Outputs	25
4.4.2	Signals and Error Codes for the Inputs and Outputs	25
4.4.3	Digital Inputs	25
4.4.4	Digital outputs	27
5	Operation	28
5.1	Handling	28
5.2	Diagnosis	28
6	Maintenance	29
6.1	Faults	29
6.2	Maintenance Measures	30
6.2.1	Loading the Operating System	30
6.2.2	Proof Test	30
7	Decommissioning	31
8	Transport	32
9	Disposal	33
	Appendix	35
	Glossary	35
	Index of Figures	36
	Index of Tables	37
	Index	38

1 Introduction

This manual describes the technical characteristics of the module and its use. It also includes instructions on how to install, start up and replace it.

1.1 Structure and Use of this Manual

The content of this manual is part of the hardware description of the HIMatrix programmable electronic system.

This manual is organized in the following main chapters:

- Introduction
- Safety
- Product Description
- Start-Up
- Operation
- Maintenance
- Decommissioning
- Transport
- Disposal

This manual distinguishes between the following variants of the HIMatrix system:

Programming tool	Processor operating system	Communication operating system
SILworX	Versions beyond 7	Version 12 and beyond
ELOP II Factory	Versions prior to 7	Versions prior to 12

Table 1: HIMatrix System Variants

The manual distinguishes among the different variants using:

- Separated chapters,
- Tables differentiating among the versions, e.g., versions beyond 7, or prior to 7.



Projects created with ELOP II Factory cannot be edited with SILworX, and vice versa!



This manual usually refers to compact controllers and remote I/Os as *devices*, and to the plug-in cards of a modular controller as *modules*.

Additionally, the following documents must be taken into account:

Name	Content	Document number
HIMatrix System Manual Compact Systems	Hardware description of the HIMatrix compact systems	HI 800 141 E
HIMatrix System Manual Modular System F60	Hardware description of the HIMatrix modular system	HI 800 191 E
Himatrix Safety Manual	Safety functions of the HIMatrix system	HI 800 023 E
HIMatrix Engineering Manual	Project planning description for HIMatrix systems	HI 800 101 E
SILworX Online Help	Instructions on how to use SILworX	-
ELOP II Factory Online Help	Instructions on how to use ELOP II Factory, Ethernet IP protocol, INTERBUS protocol	-
First Steps SILworX	Introduction to SILworX using the HIMax system as an example	HI 801 103 E
First Steps ELOP II Factory	Introduction to ELOP II Factory	HI 800 006 E

Table 2: Additional Relevant Documents

The latest manuals can be downloaded from the HIMA website www.hima.com. The revision index on the footer can be used to compare the current version of existing manuals with the Internet edition.

1.2 Target Audience

This document addresses system planners, configuration engineers, programmers of automation devices and personnel authorized to implement, operate and maintain the modules and systems. Specialized knowledge of safety-related automation systems is required.

1.3 Formatting Conventions

To ensure improved readability and comprehensibility, the following fonts are used in this document:

Bold:	To highlight important parts Names of buttons, menu functions and tabs that can be clicked and used in the programming tool.
<i>Italics:</i>	For parameters and system variables
Courier	Literal user inputs
RUN	Operating state are designated by capitals
Chapter 1.2.3	Cross references are hyperlinks even though they are not particularly marked. When the cursor hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position.

Safety notes and operating tips are particularly marked.

1.3.1 Safety Notes

The safety notes are represented as described below. These notes must absolutely be observed to reduce the risk to a minimum. The content is structured as follows:

- Signal word: danger, warning, caution, notice
- Type and source of danger

- Consequences arising from the danger
- Danger prevention

⚠ SIGNAL WORD



Type and source of danger!
Consequences arising from the danger
Danger prevention

The signal words have the following meanings:

- Danger indicates hazardous situation which, if not avoided, will result in death or serious injury.
- Warning indicates hazardous situation which, if not avoided, could result in death or serious injury.
- Warning indicates hazardous situation which, if not avoided, could result in minor or modest injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

NOTE



Type and source of damage!
Damage prevention

1.3.2 Operating Tips

Additional information is structured as presented in the following example:

i The text corresponding to the additional information is located here.

Useful tips and tricks appear as follows:

TIP The tip text is located here.

2 Safety

The following safety information, notes and instructions must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

This product is operated with SELV or PELV. No imminent danger results from the product itself. The use in Ex-Zone is permitted if additional measures are taken.

2.1 Intended Use

HIMatrix components are designed for assembling safety-related controller systems.

When using the components in the HIMatrix system, comply with the following general requirements

2.1.1 Environmental Requirements

Requirement type	Range of values
Protection class	Protection class III in accordance with IEC/EN 61131-2
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
Housing	Standard: IP20
Supply voltage	24 VDC

Table 3: Environmental Requirements

Exposing the HIMax system to environmental conditions other than those specified in this manual can cause the HIMatrix system to malfunction.

2.1.2 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace devices.

NOTE



Device damage due to electrostatic discharge!

- When performing the work, make sure that the workspace is free of static and wear an ESD wrist strap.
- If not used, ensure that the device is protected from electrostatic discharge, e.g., by storing it in its packaging.

2.2 Residual Risk

No imminent danger results from a HIMatrix system itself.

Residual risk may result from:

- Faults in the engineering
- Faults in the user program
- Faults in the wiring

2.3 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.

2.4 Emergency Information

A HIMatrix system is a part of the safety equipment of a site. If a device or a module fails, the site adopts the safe state.

In case of emergency, no action that may prevent the HIMatrix systems from operating safely is permitted.

3 Product Description

DIO 24/16 01 is a plug-in module for the modular F60 HIMatrix system.

The DIO 24/16 01 module has 24 digital input channels and 16 digital output channels that are galvanically isolated from the I/O bus. The status of the input and output signals is displayed by LEDs located on the front plate next to the terminal plugs.

The module can be inserted in the F60 subrack's slot 3...8 as many times as required. Slots 1 and 2 are reserved for the power supply module and CPU module, respectively.

However, the load on the outputs must not exceed the total current input of the power supply module.

The module has been certified by the TÜV for safety-related applications up to SIL 3 (IEC 61508, IEC 61511 and IEC 62061), Cat. 4 (EN 954-1) and PL e (EN ISO 13849-1). Further safety standards, application standards and test standards are specified in the certificate available on the HIMA website.

3.1 Safety Function

The module is equipped with safety-related inputs and outputs.

3.1.1 Safety-Related Analog Inputs

Each group of 8 inputs is provided with a common, short-circuit-proof supply LS+ on the clamps.

The safety-related application (SIL 3 in accordance with IEC 61508) of the inputs and the sensors connected must comply with the safety requirements. For more information, refer to the HIMatrix Safety Manual.

3.1.1.1 Reaction in the Event of a Fault

If the module detects a fault on a digital input, the user program processes a low level in accordance with the de-energized to trip principle.

The module activates the *FAULT* LED.

In addition to the channel signal value, the user program must also consider the corresponding error code.

The error code allows the user to configure additional fault reactions in the user program.

3.1.2 Safety-Related Outputs

Each group of 8 outputs is provided with a connector on the clamps for the common ground.

If an output channel is overloaded, it is switched off for ten seconds until the overload is no longer present. If the module output range has a total load of more than 8 A, the outputs are all switched off for 10 seconds and a new test is performed.

3.1.2.1 Reaction in the Event of a Fault

If the module detects a faulty signal on a digital output, the affected module output is set to the safe (de-energized) state using the safety switches.

If a fault in the module occurs, all digital outputs are switched off.

In both cases, the module activates the *FAULT* LED.

The error code allows the user to configure additional fault reactions in the user program.

3.1.3 Line Control

The digital outputs DO 1 through DO 8 of the DIO 24/16 01 module can be used to monitor the own digital inputs or the digital inputs of other modules (e.g., DI 32 01) for short-circuits and open-circuits, e.g., for an EMERGENCY STOP button complying with Cat. 4 in accordance with EN 954-1. To this end, the outputs are pulsed and connected to the safety-related digital inputs. In this case, the outputs assume the function of pulsed outputs.

The parameters for the line control are set via system parameters; refer to the HIMatrix Engineering Manual for more details.

i

Pulsed outputs must not be used as safety-related outputs!

3.2 Equipment, Scope of Delivery

The following list specifies the available components and the corresponding part numbers:

Designation	Description	Part no.
DIO 24/16 01	Plug-in module with 24 digital inputs and 16 digital outputs.	98 2200100

Table 4: Part Numbers

3.3 Type Label

The type plate contains the following details:

- Product name
- Bar code (1D or 2D code)
- Part no.
- Production year
- Hardware revision index (HW Rev.)
- Firmware revision index (FW Rev.)
- Operating voltage
- Mark of conformity



Figure 1: Sample Type Label

3.4 Assembly

This chapter describes the layout and function of the plug-in module.

3.4.1 Block Diagram




Figure 2: Block Diagram

3.4.2 Front View




Figure 3: Front View

3.4.3 Module Indicators

LED	Color	Status	Description
RUN	Green	On	Operating voltage present
		Off	No operating voltage
ERR	Red	On	Module faulty or external faults Reaction as dictated by the diagnosis
		Off	No module faults and / or no channel faults

Table 5: Module Indicators

3.4.4 I/O LEDs

LED	Color	Status	Description
I 1...24	Yellow	On	The related input is active (energized).
		Off	The related input is inactive (de-energized).
O 1...16	Yellow	On	The related output is active (energized).
		Off	The related output is inactive (de-energized).

Table 6: I/O LEDs

3.5 Product Data

General	
Operating voltage	24 VDC, -15 %...+20 %, $w_{ss} \leq 15 \%$, provided by a power supply unit with safe isolation in accordance with IEC 61131-2 requirements.
Operating data	24 VDC / 380 mA 3.3 VDC / 150 mA
Ambient temperature	0 °C...+60 °C
Storage temperature	-40 °C...+85 °C
Space requirement	6 RU, 4 HP
Weight	260 g

Table 7: Product Data

Digital Inputs	
Number of inputs	24 (galvanically isolated)
Input voltage High level Low level	nom. 24 VDC 10 V...30 V max. 5 V
Input current High level Low level	2 mA at 10 V, 5 mA at 24 V 1 mA at 5 V
Switching point	typ. 7.5 V
Supply	3 x 20 V / 100 mA (at 24 V), short-circuit-proof

Table 8: Specifications for Digital Inputs

Digital outputs	
Number of outputs	16 (galvanically isolated)
Output voltage	18.4...26.8 VDC
Internal voltage drop	max. 2 W at 2 A
Output current (at 30 °C)	2 A each channel, max. 8 A each module, permanently short-circuit-proof
Minimum load	2 mA for each channel
Leakage current (low level)	max. 1 mA at 2 V

Table 9: Specifications for the Digital Outputs

4 Start-Up

To start up the controller, it must be mounted, connected and configured in the programming tool.

4.1 Installation and Mounting

The module is mounted in the subrack of the modular HIMatrix F60 system.

4.1.1 Mounting and Removing the Modules

To mount and remove the modules, the connection cable clamp terminals must be unplugged.

Additionally, personnel must be protected from electrostatic discharge. For details, refer to Chapter 2.1.2.

Mounting the Modules

To mount a module into the rack

1. Insert the module as far as it can go – without jamming it – into the two guiding rails which are located on the on the housing's upper and lower part.
2. Apply pressure to the upper and lower extremity of the front plate until the module plugs snap into the backplane socket.
3. Secure the module with the screws located on upper and lower extremity of the front plate.

The module is mounted.

Removing the Modules

To remove a module from the rack

1. Remove the plugs from the module front plate.
2. Release the locking screws located on the upper and lower extremity of the front plate.
3. Loosen the module using the handle located on the lower part of the front plate and remove it from the guiding rails.

The module is removed.

The use of shielded cables is not required, but improves the EMC conditions significantly. To allow the connection of the clamps to the earth grid of the F60, the diameter of the cable shielding should not exceed 12 mm.

The inputs and outputs are connected using 9-pole connectors with numbered terminals. The terminal pins on the front plate of the module have the same numbered sequence to avoid improper connections.

4.1.2 Connecting the Digital Inputs

Use the following terminals to connect the digital inputs:

Terminal	Designation	Function
01	LS+	Supply of inputs 1...8
02	I1	Digital input 1
03	I2	Digital input 2
04	I3	Digital input 3
05	I4	Digital input 4
06	I5	Digital input 5
07	I6	Digital input 6
08	I7	Digital input 7
09	I8	Digital input 8
Terminal	Designation	Function
10	LS+	Supply of inputs 9...16
11	I9	Digital input 9
12	I10	Digital input 10
13	I11	Digital input 11
14	I12	Digital input 12
15	I13	Digital input 13
16	I14	Digital input 14
17	I15	Digital input 15
18	I16	Digital input 16
Terminal	Designation	Function
19	LS+	Supply of inputs 17...24
20	I17	Digital input 17
21	I18	Digital input 18
22	I19	Digital input 19
23	I20	Digital input 20
24	I21	Digital input 21
25	I22	Digital input 22
26	I23	Digital input 23
27	I24	Digital input 24

Table 10: Terminal Assignment for the Digital Inputs

4.1.2.1 Surges on Digital Inputs

Due to the short cycle time of the HIMatrix systems, a surge pulse as described in EN 61000-4-5 can be read in to the digital inputs as a short-term high level.

The following measures ensure proper operation in environments where surges may occur:

1. Install shielded input wires
2. Activate noise blanking: a signal must be present for at least two cycles before it is evaluated.



Activating noise blanking increases the response time of the HIMatrix system!



The measures specified above are not necessary if the plant design precludes surges from occurring within the system.

In particular, the design must include protective measures with respect to overvoltage, lightning, earth grounding and plant wiring in accordance with the relevant standards and the instructions specified in the System Manual (HI 800 141 or HI 800 191).

4.1.3 Connecting the Digital Outputs

Use the following terminals to connect the digital outputs:

Terminal	Designation	Function
28	L-	Supply of outputs 1...8
29	O1	Digital output 1
30	O2	Digital output 2
31	O3	Digital output 3
32	O4	Digital output 4
33	O5	Digital output 5
34	O6	Digital output 6
35	O7	Digital output 7
36	O8	Digital output 8
Terminal	Designation	Function
37	L-	Supply of outputs 9...16
38	O9	Digital output 9
39	O10	Digital output 10
40	O11	Digital output 11
41	O12	Digital output 12
42	O13	Digital output 13
43	O14	Digital output 14
44	O15	Digital output 15
45	O16	Digital output 16

Table 11: Terminal Assignment for the Digital Outputs

4.1.4 Mounting the DIO 24/16 01 in Zone 2

(EC Directive 94/9/EC, ATEX)

The device is suitable for mounting in zone 2. Refer to the corresponding declaration of conformity available on the HIMA website.

When mounting the device, observe the special conditions specified in the following section.

Special Conditions X

1. The HIMatrix F60 DIO 24/16 01 must be mounted in an enclosure, which fulfills the requirements of the EN 60079-15 with the type of protection at least IP 54, according to EN 60529. Provide the enclosure with the following label:

Work is only permitted in the de-energized state

Exception:

If a potentially explosive atmosphere has been precluded, work can also be performed when the controller is under voltage.

2. The enclosure in use must be able to safely dissipate the generated heat. The power dissipation (PV) of each HIMatrix F60 DIO 24/16 01 module is 25 W at maximum output load.
3. The HIMatrix F60 DIO 24/16 01 module must be supplied with 24 VDC from a power supply unit with safe isolation. Only power supply units of type PELV or SELV may be used.
4. Applicable standards:

VDE 0170/0171 Part 16,	DIN EN 60079-15: 2004-5
VDE 0165 Part 1,	DIN EN 60079-14: 1998-08

Pay particular attention to the following sections:

DIN EN 60079-15:

Chapter 5	Design
Chapter 6	Terminals and cabling
Chapter 7	Air and creeping distances
Chapter 14	Connectors

DIN EN 60079-14:

Chapter 5.2.3	Equipment for use in zone 2
Chapter 9.3	Cabling for zones 1 and 2
Chapter 12.2	Equipment for zones 1 and 2

The controller is additionally equipped with the label represented below:



Figure 4: Label for Ex Conditions

4.2 Configuration

The DIO 24/16 01 can be configured using a programming tool, SILworX or ELOP II Factory. Which programming tool should be used depends on the revision status of the operating system (firmware):

- ELOP II Factory is required for operating system versions prior to 7.
- SILworX is required for operating system version 7 and beyond.

i

ELOP II Factory is required to load a new operating system (version 7 or beyond) into a controller with a CPU operating system version prior to 7. SILworX is then required once the loading procedure is completed.

4.2.1 Module Slots

Slots 1 and 2 on the F60 module rack are reserved for the PS 01 power supply module and CPU module, respectively. Any type of I/O modules can be plugged in to slots 3...8.

The module slots in SILworX and ELOP II Factory are numbered as follows:

Module	Slot on the rack	Slot in SILworX	Slot in ELOP II Factory
PS 01	1	-	-
CPU/COM	2	0/1	-
I/O	3	2	1
I/O	4	3	2
I/O	5	4	3
I/O	6	5	4
I/O	7	6	5
I/O	8	7	6

Table 12: Module Slots

i

- The PS 01 power supply module is not configured.
- CPU and COM are both on the F 60 CPU 01 module. In the programming tools, however, they are represented as separated items.

4.3 Configuring the Module with SILworX

In the Hardware Editor, the controller is represented with the following modules:

- one processor module (CPU)
- one communication module
- 6 slots available for I/O modules

To insert I/O modules, drag them from the module list onto an available slot.

Double-click the module to open the Detail View with the corresponding tabs. The tabs are used to assign the global variables configured in the user program to the system parameters of the corresponding module.

4.3.1 Parameters and Error Codes for the Inputs and Outputs

The following tables specify the system parameters that can be read and set for the inputs and outputs, including the corresponding error codes.

In the user program, the error codes can be read using the variables assigned within the logic.

The error codes can also be displayed in SILworX.

4.3.2 Digital Inputs and Outputs

The following tables present the statuses and parameters for the input and the output module in the same order as given in the Hardware Editor.

4.3.2.1 Module Tab

The **Module** tab contains the following system parameters.

System parameter	Data type	R/W	Description	
DI Number of Pulsed Channels	USINT	W	Number of pulsed outputs (supply outputs)	
			Coding	Description
			0	No output planned for LS/LB ¹⁾ detection
			1	Output channel 1 planned for LS/LB ¹⁾ detection
			2	Output channels 1...2 planned for LS/LB ¹⁾ detection
		
8	Output channels 1...8 planned for LS/LB ¹⁾ detection			
			<i>Pulsed outputs must not be used as safety-related outputs!</i>	
DI Pulse Slot	UDINT	W	Pulse module slot: Value 1...6, according to the actual slot on the right of the CPU	
DI Pulse Delay (10E-6s)	UINT	W	Waiting time for line control (detection of short-circuits or cross-circuits)	
DI.Error Code	WORD	R	Error codes for all digital inputs	
			Coding	Description
			0x0001	Module fault
			0x0002	FTT test of test pattern faulty

System parameter	Data type	R/W	Description																												
DO.Error Code	WORD	R	<table border="1"> <thead> <tr> <th colspan="2">Error codes for all digital outputs</th> </tr> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Module fault</td> </tr> <tr> <td>0x0002</td> <td>MOT test safety switch 1 faulty</td> </tr> <tr> <td>0x0004</td> <td>MOT test safety switch 2 faulty</td> </tr> <tr> <td>0x0008</td> <td>FTT test of test pattern faulty</td> </tr> <tr> <td>0x0010</td> <td>MOT test of the read back channels faulty</td> </tr> <tr> <td>0x0020</td> <td>MOT test active shutdown faulty</td> </tr> <tr> <td>0x0100</td> <td>FTT test of CS (chip select) signals faulty</td> </tr> <tr> <td>0x0200</td> <td>All outputs are switched off, total current exceeded</td> </tr> <tr> <td>0x0400</td> <td>FTT test: 1st temperature threshold exceeded</td> </tr> <tr> <td>0x0800</td> <td>FTT test: 2nd Temperature threshold exceeded</td> </tr> <tr> <td>0x1000</td> <td>FTT test: Monitoring of auxiliary voltage 1: Low voltage</td> </tr> <tr> <td>0x2000</td> <td>MOT test: status of safety switches</td> </tr> </tbody> </table>	Error codes for all digital outputs		Coding	Description	0x0001	Module fault	0x0002	MOT test safety switch 1 faulty	0x0004	MOT test safety switch 2 faulty	0x0008	FTT test of test pattern faulty	0x0010	MOT test of the read back channels faulty	0x0020	MOT test active shutdown faulty	0x0100	FTT test of CS (chip select) signals faulty	0x0200	All outputs are switched off, total current exceeded	0x0400	FTT test: 1st temperature threshold exceeded	0x0800	FTT test: 2nd Temperature threshold exceeded	0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage	0x2000	MOT test: status of safety switches
			Error codes for all digital outputs																												
			Coding	Description																											
			0x0001	Module fault																											
			0x0002	MOT test safety switch 1 faulty																											
			0x0004	MOT test safety switch 2 faulty																											
			0x0008	FTT test of test pattern faulty																											
			0x0010	MOT test of the read back channels faulty																											
			0x0020	MOT test active shutdown faulty																											
			0x0100	FTT test of CS (chip select) signals faulty																											
			0x0200	All outputs are switched off, total current exceeded																											
			0x0400	FTT test: 1st temperature threshold exceeded																											
			0x0800	FTT test: 2nd Temperature threshold exceeded																											
			0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage																											
0x2000	MOT test: status of safety switches																														
Module Error Code	[WORD]	R	<table border="1"> <thead> <tr> <th colspan="2">Error codes for the module</th> </tr> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0000</td> <td>I/O processing, if required with errors see other error codes</td> </tr> <tr> <td>0x0001</td> <td>No I/O processing (CPU not in RUN)</td> </tr> <tr> <td>0x0002</td> <td>No I/O processing during the booting test</td> </tr> <tr> <td>0x0004</td> <td>Manufacturer interface operating</td> </tr> <tr> <td>0x0010</td> <td>No I/O processing: wrong configuration</td> </tr> <tr> <td>0x0020</td> <td>No I/O processing: fault rate exceeded</td> </tr> <tr> <td>0x0040/ 0x0080</td> <td>No I/O processing: configured module not plugged in</td> </tr> </tbody> </table>	Error codes for the module		Coding	Description	0x0000	I/O processing, if required with errors see other error codes	0x0001	No I/O processing (CPU not in RUN)	0x0002	No I/O processing during the booting test	0x0004	Manufacturer interface operating	0x0010	No I/O processing: wrong configuration	0x0020	No I/O processing: fault rate exceeded	0x0040/ 0x0080	No I/O processing: configured module not plugged in										
			Error codes for the module																												
			Coding	Description																											
			0x0000	I/O processing, if required with errors see other error codes																											
			0x0001	No I/O processing (CPU not in RUN)																											
			0x0002	No I/O processing during the booting test																											
			0x0004	Manufacturer interface operating																											
			0x0010	No I/O processing: wrong configuration																											
			0x0020	No I/O processing: fault rate exceeded																											
0x0040/ 0x0080	No I/O processing: configured module not plugged in																														
Module SRS	UDINT	R	Slot number (System Rack Slot)																												
Module Type	UINT	R	Type of module, target value: 0xFE01 [65025 _{dec}]																												
¹⁾ LS/LB (LS = short-circuit, LB = open-circuit)																															

Table 13: SILworX - System Parameters for Digital Outputs and Inputs, **Module** Tab

4.3.2.2 DIO 24/16 01_1: DO Channels Tab

The **DIO 24/16 01_1: DO Channels** tab contains the following system variables:

System parameter	Data type	R/W	Description								
-> Error Code [BYTE]	BYTE	R	Input values for the digital input channels 0 = input de-energized 1 = input energized								
Value [BOOL] ->	BOOL	R	Error codes for the digital output channels <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital output module</td> </tr> <tr> <td>0x02</td> <td>Channel shutdown due to overload</td> </tr> <tr> <td>0x04</td> <td>Error while reading back the digital outputs</td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital output module	0x02	Channel shutdown due to overload	0x04	Error while reading back the digital outputs
Coding	Description										
0x01	Fault in the digital output module										
0x02	Channel shutdown due to overload										
0x04	Error while reading back the digital outputs										

Table 14: SILworX - System Parameters for Digital Outputs, **DIO 24/16 01_01: DO Channels** Tab

4.3.2.3 DIO 24/16 01_1: DI Channels Tab

The **DIO 24/16 01_1: DI Channels** tab contains the following system variables:

System parameter	Data type	R/W	Description												
-> Error Code [BYTE]	BYTE	R	Error codes for the digital output channels <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital input module</td> </tr> <tr> <td>0x10</td> <td>Short-circuit of the channel</td> </tr> <tr> <td>0x80</td> <td>Intermittence between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage </td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital input module	0x10	Short-circuit of the channel	0x80	Intermittence between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 				
Coding	Description														
0x01	Fault in the digital input module														
0x10	Short-circuit of the channel														
0x80	Intermittence between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 														
-> Value [BOOL]	BOOL	R	Input values for the digital input channels 0 = input de-energized 1 = input energized												
Pulse Channel [USINT] ->	USINT	W	Source channel for pulsed supply <table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Input channel</td> </tr> <tr> <td>1</td> <td>Pulse of the 1st DO channel</td> </tr> <tr> <td>2</td> <td>Pulse of the 2nd DO channel</td> </tr> <tr> <td>...</td> <td></td> </tr> <tr> <td>8</td> <td>Pulse of the 8th DO channel</td> </tr> </tbody> </table>	Coding	Description	0	Input channel	1	Pulse of the 1st DO channel	2	Pulse of the 2nd DO channel	...		8	Pulse of the 8th DO channel
Coding	Description														
0	Input channel														
1	Pulse of the 1st DO channel														
2	Pulse of the 2nd DO channel														
...															
8	Pulse of the 8th DO channel														

Table 15: SILworX - System Parameters for Digital Inputs, **DIO 24/16 01_01: DI Channels** Tab

4.4 Configuring a Module Using ELOP II Factory

4.4.1 Configuring the Inputs and Outputs

The signals previously defined in the Signal Editor (Hardware Management) are assigned to the individual channels (inputs and outputs) using ELOP II Factory. Refer to the System Manual for Compact Systems or the online help for more details

The following chapter describes the system signals used for assigning signals in the controller.

4.4.2 Signals and Error Codes for the Inputs and Outputs

The following tables specify the system signals that can be read and set for the inputs and outputs, including the corresponding error codes.

In the user program, the error codes can be read using the signals assigned within the logic.

The error codes can also be displayed in ELOP II Factory.

4.4.3 Digital Inputs

System Signal	R/W	Description																
Mod.SRS [UDINT]	R	Slot number (System Rack Slot)																
Mod. Type [UINT]	R	Type of module, target value: 0xFE01 [65025 _{dec}]																
Mod. Error Code [WORD]	R	Error codes for the module																
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0000</td> <td>I/O processing, if required with errors see other error codes</td> </tr> <tr> <td>0x0001</td> <td>No I/O processing (CPU not in RUN)</td> </tr> <tr> <td>0x0002</td> <td>No I/O processing during the booting test</td> </tr> <tr> <td>0x0004</td> <td>Manufacturer interface operating</td> </tr> <tr> <td>0x0010</td> <td>No I/O processing: wrong configuration</td> </tr> <tr> <td>0x0020</td> <td>No I/O processing: fault rate exceeded</td> </tr> <tr> <td>0x0040/ 0x0080</td> <td>No I/O processing: configured module not plugged in</td> </tr> </tbody> </table>	Coding	Description	0x0000	I/O processing, if required with errors see other error codes	0x0001	No I/O processing (CPU not in RUN)	0x0002	No I/O processing during the booting test	0x0004	Manufacturer interface operating	0x0010	No I/O processing: wrong configuration	0x0020	No I/O processing: fault rate exceeded	0x0040/ 0x0080	No I/O processing: configured module not plugged in
		Coding	Description															
		0x0000	I/O processing, if required with errors see other error codes															
		0x0001	No I/O processing (CPU not in RUN)															
		0x0002	No I/O processing during the booting test															
		0x0004	Manufacturer interface operating															
		0x0010	No I/O processing: wrong configuration															
0x0020	No I/O processing: fault rate exceeded																	
0x0040/ 0x0080	No I/O processing: configured module not plugged in																	
DI.Error Code [WORD]	R	Error codes for all digital inputs																
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Module fault</td> </tr> <tr> <td>0x0002</td> <td>FTT test of test pattern faulty</td> </tr> </tbody> </table>	Coding	Description	0x0001	Module fault	0x0002	FTT test of test pattern faulty										
		Coding	Description															
0x0001	Module fault																	
0x0002	FTT test of test pattern faulty																	
DI[xx].Error Code [BYTE]	R	Error codes for the digital input channels																
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital input module</td> </tr> <tr> <td>0x10</td> <td>Short-circuit of the channel</td> </tr> <tr> <td>0x80</td> <td>Intermittence between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage </td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital input module	0x10	Short-circuit of the channel	0x80	Intermittence between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 								
		Coding	Description															
		0x01	Fault in the digital input module															
0x10	Short-circuit of the channel																	
0x80	Intermittence between pulsed output DO and digital input DI, e.g., <ul style="list-style-type: none"> ▪ Open-circuit ▪ Open switch ▪ L+ low voltage 																	

System Signal	R/W	Description												
DI[xx].Value [BOOL]	R	Input values for the digital input channels 0 = input de-energized 1 = input energized												
DI Number of Pulsed Channels [USINT]	W	Number of pulsed outputs (supply outputs) <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>No output planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>1</td> <td>Output channel 1 planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>2</td> <td>Output channels 1...2 planned for LS/LB¹⁾ detection</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>8</td> <td>Output channels 1...8 planned for LS/LB¹⁾ detection</td> </tr> </tbody> </table> <p>Pulsed outputs must not be used as safety-related outputs!</p>	Coding	Description	0	No output planned for LS/LB ¹⁾ detection	1	Output channel 1 planned for LS/LB ¹⁾ detection	2	Output channels 1...2 planned for LS/LB ¹⁾ detection	8	Output channels 1...8 planned for LS/LB ¹⁾ detection
Coding	Description													
0	No output planned for LS/LB ¹⁾ detection													
1	Output channel 1 planned for LS/LB ¹⁾ detection													
2	Output channels 1...2 planned for LS/LB ¹⁾ detection													
...	...													
8	Output channels 1...8 planned for LS/LB ¹⁾ detection													
DI Pulse Slot [UDINT]	W	Pulse module slot: Value 1...6, according to the actual slot on the right of the CPU												
DI[xx].Pulsed Channel [USINT]	W	Source channel for pulsed supply <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 20%;">Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Input channel</td> </tr> <tr> <td>1</td> <td>Pulse of the 1st DO channel</td> </tr> <tr> <td>2</td> <td>Pulse of the 2nd DO channel</td> </tr> <tr> <td>...</td> <td></td> </tr> <tr> <td>8</td> <td>Pulse of the 8th DO channel</td> </tr> </tbody> </table>	Coding	Description	0	Input channel	1	Pulse of the 1st DO channel	2	Pulse of the 2nd DO channel	...		8	Pulse of the 8th DO channel
Coding	Description													
0	Input channel													
1	Pulse of the 1st DO channel													
2	Pulse of the 2nd DO channel													
...														
8	Pulse of the 8th DO channel													
DI Pulse Delay [10E-6 s] [UINT]	W	Waiting time for line control (detection of short-circuits or cross-circuits)												
¹⁾ LS/LB (LS = short-circuit, LB = open-circuit)														

Table 16: ELOP II Factory - Digital Input System Signals

4.4.4 Digital outputs

System Signal	R/W	Description																										
Mod.SRS [UDINT]	R	Slot number (System Rack Slot)																										
Mod. Type [UINT]	R	Type of module, target value: 0xFE01 [65025 _{dec}]																										
Mod. Error Code [WORD]	R	Error codes for the module																										
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0000</td> <td>I/O processing, if required with errors see other error codes</td> </tr> <tr> <td>0x0001</td> <td>No I/O processing (CPU not in RUN)</td> </tr> <tr> <td>0x0002</td> <td>No I/O processing during the booting test</td> </tr> <tr> <td>0x0004</td> <td>Manufacturer interface operating</td> </tr> <tr> <td>0x0010</td> <td>No I/O processing: wrong configuration</td> </tr> <tr> <td>0x0020</td> <td>No I/O processing: fault rate exceeded</td> </tr> <tr> <td>0x0040/ 0x0080</td> <td>No I/O processing: configured module not plugged in</td> </tr> </tbody> </table>	Coding	Description	0x0000	I/O processing, if required with errors see other error codes	0x0001	No I/O processing (CPU not in RUN)	0x0002	No I/O processing during the booting test	0x0004	Manufacturer interface operating	0x0010	No I/O processing: wrong configuration	0x0020	No I/O processing: fault rate exceeded	0x0040/ 0x0080	No I/O processing: configured module not plugged in										
		Coding	Description																									
		0x0000	I/O processing, if required with errors see other error codes																									
		0x0001	No I/O processing (CPU not in RUN)																									
		0x0002	No I/O processing during the booting test																									
		0x0004	Manufacturer interface operating																									
		0x0010	No I/O processing: wrong configuration																									
0x0020	No I/O processing: fault rate exceeded																											
0x0040/ 0x0080	No I/O processing: configured module not plugged in																											
DO.Error Code [WORD]	R	Error codes for all digital outputs																										
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Module fault</td> </tr> <tr> <td>0x0002</td> <td>MOT test safety switch 1 faulty</td> </tr> <tr> <td>0x0004</td> <td>MOT test safety switch 2 faulty</td> </tr> <tr> <td>0x0008</td> <td>FTT test of test pattern faulty</td> </tr> <tr> <td>0x0010</td> <td>MOT test of the read back channels faulty</td> </tr> <tr> <td>0x0020</td> <td>MOT test active shutdown faulty</td> </tr> <tr> <td>0x0100</td> <td>FTT test of CS (chip select) signals faulty</td> </tr> <tr> <td>0x0200</td> <td>All outputs are switched off, total current exceeded</td> </tr> <tr> <td>0x0400</td> <td>FTT test: 1st temperature threshold exceeded</td> </tr> <tr> <td>0x0800</td> <td>FTT test: 2nd Temperature threshold exceeded</td> </tr> <tr> <td>0x1000</td> <td>FTT test: Monitoring of auxiliary voltage 1: Low voltage</td> </tr> <tr> <td>0x2000</td> <td>MOT test: status of safety switches</td> </tr> </tbody> </table>	Coding	Description	0x0001	Module fault	0x0002	MOT test safety switch 1 faulty	0x0004	MOT test safety switch 2 faulty	0x0008	FTT test of test pattern faulty	0x0010	MOT test of the read back channels faulty	0x0020	MOT test active shutdown faulty	0x0100	FTT test of CS (chip select) signals faulty	0x0200	All outputs are switched off, total current exceeded	0x0400	FTT test: 1st temperature threshold exceeded	0x0800	FTT test: 2nd Temperature threshold exceeded	0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage	0x2000	MOT test: status of safety switches
		Coding	Description																									
		0x0001	Module fault																									
		0x0002	MOT test safety switch 1 faulty																									
		0x0004	MOT test safety switch 2 faulty																									
		0x0008	FTT test of test pattern faulty																									
		0x0010	MOT test of the read back channels faulty																									
		0x0020	MOT test active shutdown faulty																									
		0x0100	FTT test of CS (chip select) signals faulty																									
		0x0200	All outputs are switched off, total current exceeded																									
		0x0400	FTT test: 1st temperature threshold exceeded																									
		0x0800	FTT test: 2nd Temperature threshold exceeded																									
0x1000	FTT test: Monitoring of auxiliary voltage 1: Low voltage																											
0x2000	MOT test: status of safety switches																											
DO[xx].Error Code [BYTE]	R	Error codes for the digital output channels																										
		<table border="1"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x01</td> <td>Fault in the digital output module</td> </tr> <tr> <td>0x02</td> <td>Channel shutdown due to overload</td> </tr> <tr> <td>0x04</td> <td>Error while reading back the digital outputs</td> </tr> </tbody> </table>	Coding	Description	0x01	Fault in the digital output module	0x02	Channel shutdown due to overload	0x04	Error while reading back the digital outputs																		
		Coding	Description																									
		0x01	Fault in the digital output module																									
0x02	Channel shutdown due to overload																											
0x04	Error while reading back the digital outputs																											
DO[xx].Value [BOOL]	R	Output values of the digital output channels																										
		0 = output de-energized 1 = Output activated																										

Table 17: ELOP II Factory - Digital Output System Signals

5 Operation

The module runs within a HIMatrix base plate and does not require any specific monitoring.

5.1 Handling

Handling of the controller during operation is not required.

5.2 Diagnosis

A first diagnosis results from evaluating the LEDs, see Chapter 3.4.3.

The device's diagnostic history can also be read using the programming tool.

6 Maintenance

No maintenance measures are required during normal operation.

If a device or module fails, it must be replaced with a faultless device or module of the same type or with an approved replacement model.

Only the manufacturer is authorized to repair the device/module.

6.1 Faults

Refer to Chapter 3.1.1.1, for more information on the fault reaction of inputs.

Refer to Chapter 3.1.2.1, for more information on the fault reaction of the outputs.

NOTE



If a failure occurs, the module must be replaced to ensure the plant's safety.

A module may only be replaced while the power is switched off.

i

Modules may not be removed or inserted during operation.

The instructions specified in Chapter 4.1.1 must be observed when replacing an existing module or installing a new one.

6.2 Maintenance Measures

The following measures are rarely required for the processor module:

- Loading the operating system, if a new version is required
- Executing the proof test

6.2.1 Loading the Operating System

HIMA is continuously improving the operating system of the controller. HIMA recommends to use system downtimes to load a current version of the operating system into the controller.

Refer to the release list to check the consequences of the new operation system version on the system!

Load the operating system using the programming tool.

Prior to loading the operating system, the controller must be in STOP (displayed in the programming tool). Otherwise, stop the controller.

For more information, refer to the programming tool documentation.

6.2.2 Proof Test

Test the HIMatrix modules every 10 years. For more information, refer to the Safety Manual (HI 800 003).

7 Decommissioning

Remove the supply voltage to decommission the module. Afterwards pull out the pluggable screw terminal connector blocks for inputs and outputs and the Ethernet cables.

8 Transport

To avoid mechanical damage, HIMatrix components must be transported in packaging.

Always store HIMatrix components in their original product packaging. This packaging also provides protection against electrostatic discharge. Note that the product packaging alone is not suitable for transmission.

9 Disposal

Industrial customers are responsible for correctly disposing of decommissioned HIMatrix hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.

Appendix

Glossary

Term	Description
ARP	Address Resolution Protocol: Network protocol for assigning the network addresses to hardware addresses
AI	Analog Input
COM	COMmunication module
CRC	Cyclic Redundancy Check
DI	Digital Input
DO	Digital Output
ELOP II Factory	Programming tool for HIMatrix systems
EMC	ElectroMagnetic Compatibility
EN	European Norm
ESD	ElectroStatic Discharge
FB	FieldBus
FBD	Function Block Diagrams
FTA	Field Termination Assembly
FTT	Fault Tolerance Time
ICMP	Internet Control Message Protocol: Network protocol for status or error messages
IEC	International Electrotechnical Commission
MAC address	Media Access Control address: Hardware address of one network connection
PADT	Programming And Debugging Tool (in accordance with IEC 61131-3), PC with SILworX or ELOP II Factory
PE	Protective Earth
PELV	Protective Extra Low Voltage
PES	Programmable Electronic System
PFD	Probability of Failure on Demand, probability of failure on demand of a safety function
PFH	Probability of Failure per Hour, probability of a dangerous failure per hour
R	Read: The system variable or signal provides value, e.g., to the user program
Rack ID	Base plate identification (number)
Non-reactive	Supposing that two input circuits are connected to the same source (e.g., a transmitter). An input circuit is termed <i>non-reactive</i> if it does not distort the signals of the other input circuit.
R/W	Read/Write (column title for system variable/signal type)
SB	System Bus (module)
SELV	Safety Extra Low Voltage
SFF	Safe Failure Fraction, portion of safely manageable faults
SIL	Safety Integrity Level (in accordance with IEC 61508)
SILworX	Programming tool for HIMatrix systems
SNTP	Simple Network Time Protocol (RFC 1769)
S.R.S	System.Rack.Slot addressing of a module
SW	Software
TMO	TiMeOut
W	Write: System variable/signal is provided with value, e.g., from the user program
WD	WatchDog: Time monitoring for modules or programs. If the watchdog time is exceeded, the module or program enters the ERROR STOP state.
WDT	WatchDog Time

Index of Figures

Figure 1: Sample Type Label	12
Figure 2: Block Diagram	13
Figure 3: Front View	14
Figure 4: Label for Ex Conditions	20

Index of Tables

Table 1:	HIMatrix System Variants	5
Table 2:	Additional Relevant Documents	6
Table 3:	Environmental Requirements	8
Table 4:	Part Numbers	11
Table 5:	Module Indicators	15
Table 6:	I/O LEDs	15
Table 7:	Product Data	15
Table 8:	Specifications for Digital Inputs	15
Table 9:	Specifications for the Digital Outputs	16
Table 10:	Terminal Assignment for the Digital Inputs	18
Table 11:	Terminal Assignment for the Digital Outputs	19
Table 12:	Module Slots	21
Table 13:	SILworX - System Parameters for Digital Outputs and Inputs, Module Tab	23
Table 14:	SILworX - System Parameters for Digital Outputs, DIO 24/16 01_01: DO Channels Tab	24
Table 15:	SILworX - System Parameters for Digital Inputs, DIO 24/16 01_01: DI Channels Tab	24
Table 16:	ELOP II Factory - Digital Input System Signals	26
Table 17:	ELOP II Factory - Digital Output System Signals	27

Index

diagnosis	28	line control	11
fault reaction		part number	11
digital inputs	10	specifications	15
digital outputs	11	surge.....	19



SAFETY
NONSTOP

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Tel: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com Internet: www.hima.com

(1022)